


Fixture overview



Key

- 1. Power button
- 2. Rotate button
- 3. AC power inlet
- 4. Lens carrier
- 5. Projector body
- 6. Mounting bracket (yoke)
- 13. Spring clip
- 15. Rotating belt
- 7. Lens ring
- 8. Mounting bracket screws
- 9. Front panel screws
- 10. Lens
- 11. Fuse
- 12. Gobo
- 14. Rotator



front

front interior



rear